

SNMP-NV6
UPS SNMP Card
(Web-Based monitoring SNMP Card)



User's Manual

About this manual

This manual contains information about the installation and the operation of the SNMP-NV6 SNMP card.

Save this Manual

This manual contains instructions and warnings that should be followed during the installation, operation and storage of this product. Failure to heed these instructions and warnings will void the product warranty.

Electromagnetic Interference

This is a Class A product. In a domestic environment, this product might cause radio interference in which case the user is required to take adequate measures. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

DOS, Windows: NT, 2000, XP, 2003, Vista, and 7 are registered trademarks of Microsoft Corporation. All other trademarks belong to their respective proprietors.

Safety Information

- Qualified service personnel must perform the servicing of this equipment. Remove rings, watches and other jewelry before servicing the unit.
- Before plugging in or pulling out the SNMP-NV6 card to and/or from the UPS, we recommend turning the UPS off.

Table of Contents

1. Overview	6
1.1 Features	6
1.2 Package Contents	7
2. Description	7
2.1 Ports	7
2.1.1 LED Indicators	8
2.1.2 Dipswitch Settings	8
3. Installation	8
4. Configuration Methods	9
4.1 Configure the SNMP-NV6 card by EzSetting	9
4.2 Configure the SNMP-NV6 card through COM Port	10
4.3 Configure the SNMP-NV6 card through Telnet	11
4.4 Configure the SNMP-NV6 card via Text Mode	11
4.4.1 SNMP-NV6 card's Main Menu	11
4.4.1.1 User Manager	12
4.4.1.2 TCP/IP Setting	13
4.4.1.3 Network Parameter	14
4.4.1.4 Time Server	15
4.4.1.5 Soft Restart	15
4.4.1.6 Reset All To Default	15
4.4.1.7 Exit Without Save	15
4.4.1.8 Save And Exit	15
5. Web Interface	16
5.1 Run a Web Browser	16
5.2 Monitor Information	16
5.2.1 UPS Properties	17
5.2.2 Battery Parameters	17
5.2.3 In/Out Parameters	18
5.2.4 Identification	18
5.2.5 Status Indication	19
5.2.6 ShutdownAgent	19
5.3 Monitor History	20
5.3.1 Event Log	20
5.3.2 Data Log	20
5.3.3 Configure	21
5.4 Monitor About	21
5.4.1 Information	21
5.5 Device (UPS) Management	21
5.5.1 Configure	22
5.5.1.1 Auto Restart	22
5.5.1.2 UPS Buzzer	22
5.5.1.3 Low Battery	22
5.5.1.4 UPS Shutdown Action	22
5.5.1.5 Smart Shutdown	22

5.5.1.6 Battery Replacement Date	23
5.5.1.7 External Battery Pack.....	23
5.5.1.8 Outlet Banks.....	23
5.5.1.9 Economy Mode	23
5.5.2 Control.....	23
5.5.2.1 Battery Test.....	23
5.5.2.2 Shutdown & Restart UPS Only	23
5.5.2.3 Smart Shutdown.....	24
5.5.2.4 Outlet Control	24
5.5.2.5 Power Fail/Restore Simulation.....	24
5.5.3 Weekly Schedule	24
5.5.4 Specific Schedule.....	25
5.5.5 Event Level	25
5.6 System Administration.....	26
5.6.1 User Manager	26
5.6.2 TCP/IP.....	26
5.6.2.1 TCP/IP Settings for IPv4	27
5.6.2.2 TCP/IP Settings for IPv6	27
5.6.2.3 System	27
5.6.2.4 Link.....	27
5.6.3 Web.....	27
5.6.3.1 Web.....	28
5.6.3.2 SSL Certificate	28
5.6.4 Console	28
5.6.4.1 Console	28
5.6.4.2 Host Key.....	28
5.6.4.3 Authentication Public Key	29
5.6.5 FTP	29
5.6.5.1 FTP	29
5.6.6 Time Server.....	29
5.6.6.1 Simple Network Time Server	30
5.6.6.2 Manual	30
5.6.7 Syslog	30
5.6.8 Batch Configuration.....	30
5.6.9 Upgrade	31
5.7 System Notification	32
5.7.1 SNMP Access	32
5.7.2 SNMPv3 USM (User Based Management).....	32
5.7.3 SNMP Trap	33
5.7.4 Mail Server.....	34
5.7.5 Wake On LAN	35
5.8 Environment	35
5.8.1 Information	35
5.8.2 Configuration.....	36
6. Upgrade	37

7. Specifications	39
7.1 Technical Specifications.....	39
7.2 DIP Switch Settings.....	39
7.3 LED Indicators.....	39
8. Troubleshooting	40
9. Limited Product Warranty.....	43

1. Overview

SNMP-NV6 card is an interface between the UPS and the network. It can obtain the information from a UPS and issue commands to it. SNMP-NV6 card supports two kinds of protocols – SNMP and HTTP for user access. Through the SNMP NMS and Web Browser, the user can setup the SNMP-NV6 card obtain information from the UPS and issue commands to UPS.

SNMP-NV6 card also provides shutdown software that operates with various Operating Systems that can link to the SNMP-NV6 card automatically through the network and communicate with it via SNMP protocol. The shutdown software retrieves the UPS information from SNMP-NV6 card and based on this information can start the shutdown process in order to prevent the abnormal shutdown of the host or server due to power events.

1.1 Features

- UPS network management:
 - Allows remote management of a UPS from any workstation through the Internet or Intranet
- UPS remote monitor via SNMP & HTTP:
 - Allows remote monitoring of a UPS via SNMP NMS together with the UPS MIB (Management Information Base) files or via a Web Browser
- UPS and system configuration from any client (password protected):
 - Set UPS and system parameters from a Web Browser
 - Supports Load Shedding on a Power Event
- Records event logs & monitored data:
 - Provides history data and event log for the UPS
- User notified via SNMP Trap and e-mail
- Supports gmail accounts
- Configurable SMTP server port
- Supports Network Time Protocol
- Supports Telnet configuration
- Supports BOOTP/DHCP
- Supports security protocols - HTTPS, SSH, SFTP, and SNMPv3
- Login via RADIUS and local authentication
- Supports Syslog
- Supports IPv4 and IPv6
- Supports Environmental Monitoring


1.2 Package Contents

The SNMP-NV6 card package contains the following items.

Quantity	Item
1	SNMP-NV6 SNMP Card
1	CD
1	RJ45 to DB9 serial cable
1	Quick Install
1	Product Warranty Card

2. Description

The SNMP-NV6 card's components are described as below.



2.1 Ports

Item	Description
Network Port	Connect to the Network.
LED Indicators	Indicate operational status.
Console Port	Connect to a VT100 terminal to configure the system or connect to a Temperature/Humidity Probe to monitor the environmental parameters.
Reset Button	Reset the SNMP-NV6 card only. This does not affect the UPS.
Dipswitch	Setup the operational modes.

2.1.1 LED Indicators

No.	Yellow LED	Green LED	Description
1	---	OFF	Hardware or network error
2	Flashing (1sec)	---	UPS is disconnected
Without Temp/Humidity probe			
3	Flashing (50 ms)	ON	Normal operation
With Temp/Humidity probe			
4	Flashing (50 ms)	Flashing (50 ms)	Normal operation
5	Flashing (50 ms)	ON	Temp/Humidity probe is disconnected

2.1.2 Dipswitch Settings

No.	Dip1	Dip2	Description
1	OFF	OFF	Normal operation
2	OFF	ON	Pass Through Mode
3	ON	OFF	Sensor Mode (with Temp/Humidity probe)
4	ON	ON	Console Mode

3. Installation

Note: The SNMP-NV6 cards are designed to be Hot Swappable, but there is a remote chance that when Hot-Swapping the SNMP-NV6 card that the UPS will shutdown. Minuteman recommends following steps 1 through 13 when installing the SNMP-NV6 card, but to hot-swap skip to step number 3 and omit steps 6, 7.

1. Turn off all of the equipment that is plugged into the UPS.
2. Turn off the UPS and unplug the UPS's power cord from the AC wall outlet.
3. Remove the Option Slot cover plate from the rear panel of the UPS.
4. Insert the SNMP-NV6 card into the option slot and secure with the retaining screws.
5. Connect the Network cable to the Network Port on the SNMP-NV6 card.
6. Plug the UPS's power cord into the AC wall outlet and turn the UPS on.
7. Turn on all the equipment that is plugged into the UPS.
8. Open a web browser and type in the default host name **SNMP-NV6** or the default IP address **192.168.1.100** in the address box.
9. Login as administrator with **admin** for the default Account and **password** for the default Password.
10. Open the TCP/IP page and configure the IP address, Subnet Mask, Gateway IP and the host name for the SNMP-NV6 card.
11. Open the User Manager page to change your accounts and passwords.
12. We recommended disabling the BOOTP/DHCP option and assigning a valid static IP address.
13. Open the Time Server page to set the time and the date.

Note: The BOOTP/DHCP default setting is Enabled.

4. Configuration Methods


The easiest way to configure the SNMP-NV6 card is to run the **EzSetting** program, which you can find on the provided CD. Once you have configured the essential network parameters successfully, you can launch a Web Browser or telnet to the SNMP-NV6 card to execute more detailed configuration.

4.1 Configure the SNMP-NV6 card by EzSetting

1. Prepare a workstation (Microsoft Windows 2000, 2003, 2008, XP, Vista, Win7 or later).
2. Make sure both of the dipswitches of the SNMP-NV6 card are set to the **OFF** position (normal mode) to enable the network transmission.
3. Make sure the workstation and the SNMP-NV6 card are in the same LAN.
4. Connect the Network cable to the Network Port on the SNMP-NV6 card.
5. Put the CD in and open the **EzSetting** program.

Note: The Windows Firewall may need to be turned off while using the EzSetting program.

6. Press the **Discover** button to search for all of the SNMP-NV6 cards in the LAN. All of the SNMP-NV6 cards will be listed in the **Device List** as shown below.



7. If you want to search all of the SNMP-NV6 cards in a different domain network, just change the **Subnet** and **Subnet Mask** and then press the **Discover** button to list them.
8. If the SNMP-NV6 card cannot be found, check the networking port UDP 3456 in the OS. Open it if it is blocked.

9. Select the SNMP-NV6 card in the **Device List** and then click on the **Modify** button. Enter the **account** and **password**. The default account and password are **admin** and **password** respectively.

10. Click on the **Configuration** button and then configure the essential network parameters.

4.2 Configure the SNMP-NV6 card through COM Port

1. Prepare a workstation (Microsoft Windows 2000, 2003, 2008, XP, Vista, Win7 or later).
2. Use the RJ45 to DB9 serial cable (provided) to connect the SNMP-NV6 card's COM port with the workstation's COM port.
3. Set both of the dipswitches of the SNMP-NV6 card to **OFF** position (normal mode) to enable the network transmission.
4. From the workstation running Windows 2000, 2003, 2008, or XP, open **HyperTerminal** in the **Accessories Program Group**. From the workstation running Windows Vista or 7, download the **Putty** software from the Internet to execute the configuration.
5. Configure the COM port's parameters: 2400 bps, 8 data bits, no parity, 1 stop bit and no flow control.

- Set both of the dipswitches of the SNMP-NV6 card to **ON** position (configuration mode). After the message appears on the screen, key in the **account** (default account is **admin**) and **password** (default password is **password**). Then the SNMP-NV6 card's **Main Menu** will appear on the screen. Refer to section **4.4 Configure the SNMP-NV6 card via Text Mode** for more information.

4.3 Configure the SNMP-NV6 card through Telnet

- Connect the SNMP-NV6 card to the network.
- Prepare a workstation (Microsoft Windows, Mac OS X or Linux) that is in the same LAN.
- Set both of the dipswitches of the SNMP-NV6 card to the **OFF** position (**normal mode**).
- From the Windows workstation open a DOS Prompt, type in the **telnet HostName or the IP address**. For other operating systems, please run the OS shell and type the same command.
- After the message appears on the screen, enter the **account** (default account is **admin**) and the **password** (the default password is **password**) and then the SNMP card's **Main Menu** will appear on the screen. Please refer to **4.4 Configure the SNMP-NV6 card via Text Mode** for more information.

Note: The SNMP-NV6 card will terminate the telnet connection if there is no activity within 1 minute.

4.4 Configure the SNMP-NV6 card via Text Mode

You can configure the SNMP-NV6 card via text mode by using a Telnet utility or through the COM port.

4.4.1 SNMP-NV6 card's Main Menu

```

+=====+
| Web Card Main Menu |
+=====+
Web Card Version 01.00.00
MAC Address 00-30-ab-25-e9-1e
[1]. User Manager
[2]. TCP/IP Setting
[3]. Network Parameter
[4]. Time Server
[5]. Soft Restart
[6]. Reset All To Default
[z]. Exit Without Save
[0]. Save And Exit

Please Enter Your Choice =>

```

4.4.1.1 User Manager

```

+=====+
|  User Manager  |
+=====+
RADIUS
[1]. RADIUS Auth: Disable
[2]. Server:
[3]. Secret:
[4]. Port: 1812
-----
Local Auth
  Administrator
[5]. Account: admin
[6]. Password: *****
[7]. Limitation: Only in This LAN
    Device Manager
[8]. Account: device
[9]. Password: *****
[a]. Limitation: Only in This LAN
    Read Only User
[b]. Account: user
[c]. Password: *****
[d]. Limitation: Allow Any
[0]. Back To Previous Menu

Please Enter Your Choice =>
    
```

Item	Function	Description	Default
[1].	RADIUS Auth:	Obtain the login authentication from a RADIUS server	Disable
[2].	Server:	The RADIUS server name	
[3].	Secret:	The RADIUS secret	
[4].	Port:	The RADIUS port number	1812
[5].	Administrator Account	Administrator has sole right to modify the SNMP-NV6 settings.	admin
[6].	Administrator Password		password
[7].	Administrator Limitation		Only in this LAN
[8].	Device Account	Device Manager is not permitted to change the network settings but has the ability to configure the UPS settings.	device
[9].	Device Password		password
[a].	Device Limitation	Restrict login area for the device manager	Only in this LAN
[b].	User Account	Read Only. User can observe the UPS information only.	user
[c].	User Password		password
[d].	User Limitation		Restrict login area for the user

4.4.1.2 TCP/IP Setting

```

+=====+
|  TCP/IP Setting  |
+=====+
[1]. IPv4 Address: 192.168.001.100
[2]. IPv4 Subnet Mask: 255.255.255.000
[3]. IPv4 Gateway IP: 192.168.001.254
[4]. IPv4 DNS or WINS IP: 192.168.001.001
[5]. DHCPv4 Client: Enable
[6]. IPv6 Address: fe80::230:abff:fe25:900
[7]. IPv6 Prefix Length: 64
[8]. IPv6 Gateway IP: ::
[9]. IPv6 DNS IP: ::
[a]. DHCPv6: Enable
[b]. Host Name (NetBIOS): SNMP-NV6
[c]. System Contactor:
[d]. System Location:
[e]. Auto-Negotiation: Enable
[f]. Speed: 100M
[g]. Duplex: Full
[h]. Status Stable: 3
[0]. Back To Previous Menu

Please Enter Your Choice =>

```

Item	Function	Description	Default
[1].	IPv4 Address	The default IPv4 address	192.168.001.100
[2].	IPv4 Subnet Mask	The IPv4 sub-net mask setting	255.255.255.000
[3].	IPv4 Gateway IP	The IPv4 network default gateway	192.168.001.254
[4].	IPv4 DNS IP	IPv4 Domain Name Server IP address	192.168.001.001
[5].	DHCPv4 Client	Enable/Disable DHCPv4 protocol	Enable
[6].	IPv6 Address	The SNMP-NV6 IPv6 address	
[7].	IPv6 Subnet Mask	The IPv6 sub-net mask setting	
[8].	IPv6 Gateway IP	The IPv6 network default gateway	
[9].	IPv6 DNS IP	IPv6 Domain Name Server IP address	
[a].	DHCPv6 Client	Enable/Disable DHCPv6 protocol	Enable
[b].	Host Name		SNMP-NV6
[c].	System Contactor		
[d].	System Location		
[e].	Auto-Negotiation		Enable
[f].	Speed	The network link operation	100M
[g].	Duplex		Full

4.4.1.3 Network Parameter

```

+=====+
| Network Parameter |
+=====+
[1]. HTTP Server: Enable
[2]. HTTPS Server: Enable
[3]. Telnet Server: Enable
[4]. SSH/SFTP Server: Enable
[5]. FTP Server: Enable
[6]. Syslog: Enable
[7]. HTTP Server Port: 80
[8]. HTTPS Server Port: 443
[9]. Telnet Server Port: 23
[a]. SSH Server Port: 22
[b]. FTP Server Port: 21
[c]. Syslog Server1:
[d]. Syslog Server2:
[e]. Syslog Server3:
[f]. Syslog Server4:
[g]. SNMP Get, Set Port: 161
[0]. Back To Previous Menu

Please Enter Your Choice =>
    
```

Item	Function	Description	Default
[1].	HTTP Server	Enable/Disable HTTP protocol	Enable
[2].	HTTPS Server	Enable/Disable HTTPS protocol	Enable
[3].	Telnet Server	Enable/Disable telnet protocol	Enable
[4].	SSH/SFTP Server	Enable/Disable SSH/SFTP protocol	Enable
[5].	FTP Server	Enable/Disable FTP protocol	Enable
[6].	Syslog	Enable/Disable remote syslog	Disable
[7].	HTTP Server Port	HTTP networking port	80
[8].	HTTPS Server Port	HTTPS networking port	443
[9].	Telnet Server Port	Telnet networking port	23
[a].	SSH Server Port	SSH networking port	22
[b].	FTP Server Port	FTP networking port	21
[c].	Syslog Server1	The remote syslog host name	
[d].	Syslog Server2	The remote syslog host name	
[e].	Syslog Server3	The remote syslog host name	
[f].	Syslog Server4	The remote syslog host name	
[g].	SNMP Get, Set Port	The SNMP networking port	161

4.4.1.4 Time Server

There are two ways to set the SNMP-NV6 card's current time and date. One is to set the system time manually, but this is not the best way. The ideal way is to set up a timeserver. The SNMP-NV6 card does support SNTP, which is supported by Windows XP.

To configure a Windows PC to act as a timeserver, please install the **Simple TCP/IP Services** from the **Add/Remove Windows Components**.

```

+=====+
|   Time Server   |
+=====+
[1]. Time Selection: SNTP
[2]. Time Zone: +0 hr
[3]. 1st Time Server: POOL.NTP.ORG
[4]. 2nd Time Server:
[5]. Manual Date: 01/01/2000 (MM/DD/YYYY)
[6]. Manual Time: 00:00:00 (hh:mm:ss)
[0]. Back To Previous Menu

Please Enter Your Choice =>

```

Item	Function	Description	Default
[1].	Time Selection	Select SNTP or manually	SNTP
[2].	Time Zone	Select time zone	+0 hr
[3].	1 st Time Server	The first time server for SNTP	POOL.NTP.ORG
[4].	2 nd Time Server	The second time server for SNTP	
[5].	Manual Date	Assign the date manually if the Time Selection is selected to Manual	01/01/2000
[6].	Manual Time	Assign the time manually if the Time Selection is selected to Manual	00:00:00

4.4.1.5 Soft Restart

Simply restart the SNMP-NV6 card. It does not affect the UPS.

4.4.1.6 Reset All To Default

Resets all of the settings back to the original default values.

4.4.1.7 Exit Without Save

Exit and disregard any changes.

4.4.1.8 Save And Exit

Saves the changes and exits.

5. Web Interface

5.1 Run a Web Browser

1. Make sure that you have a **TCP/IP** network already installed.
2. Start your Web Browser. Enter **http://host_name** or **http://ip_address** in the address bar for the plain web transmission or **https://host_name** or **https://ip_address** for the encrypted web transmission. The SNMP-NV6 card will then ask for your user name and password. After keying in the correct **user name** and **password**, the **SNMP-NV6 card's Home Page** will appear on the screen.



MINUTEMAN
POWER TECHNOLOGIES
by Para Systems, Inc.

User Name : admin

Password : ●●●●●●●●

OK

Site IP: 192.168.168.239

Copyright ©, All rights reserved.

3. If the login page does displayed, but you are unable to login with the correct user name and password, it might be because that the IP address that you used to login is different from the SNMP-NV6 card's IP address subnet.

Note: The SNMP-NV6 cards will automatically logout the user if there is no activity for 30-minutes.

5.2 Monitor Information

This section includes information about the UPS Properties, Battery Parameters, Input/Output Parameters, Identification, Status Indication and the ShutdownAgent. Because different models provide different information, the model you have may not display the same information.

5.2.1 UPS Properties

This page gives a snapshot of all the principal UPS parameters. The values will update automatically. To set the refresh time, select the menu Administration – Web – Web Refresh Period.

The screenshot shows the 'UPS Properties' page in the SNMP-NV6 Web interface. The page is titled 'Monitor » Information » UPS Properties'. The left sidebar contains a navigation menu with the following items: UPS Properties (selected), Battery Parameters, In/Out Parameters, Identification, Status Indication, and ShutdownAgent. The main content area is divided into several sections:

- Input:** Volt(L-N): 123.1 V, Freq: 60.0 Hz. Includes a 'Detail...' link.
- UPS Status:** Model: E750R TXL2U, Type: Line interactive, Rating: 750VA, Comm.: OK, Source: Normal. Includes a 'Detail...' link.
- Output:** Volt(L-N): 122.3 V, Load: 0 %, Freq: 60.0 Hz. Includes a 'Detail...' link.
- Schedule:** Next Power Off Time: None, Next Power On Time: None, Next Test Time: None, Next Deep Batt. Test Time: None. Includes 'Weekly...' and 'Specific...' options.
- Battery:** Status: Normal, Capacity: 100 %. Includes a 'Detail...' link.
- Countdown:** Time To Power Off: --:--, Estimated OS Delay: --:--.

At the bottom right, there is an 'Event Log...' link. The footer contains the copyright notice: 'Copyright © 2012 Para Systems, Inc. All Rights Reserved.'

5.2.2 Battery Parameters

This page displays a list of the UPS battery parameters.

The screenshot shows the 'Battery Parameters' page in the SNMP-NV6 Web interface. The page is titled 'Monitor » Information » Battery Parameters'. The left sidebar contains a navigation menu with the following items: UPS Properties, Battery Parameters (selected), In/Out Parameters, Identification, Status Indication, and ShutdownAgent. The main content area is divided into two sections:

- Battery Parameters:**
 - Battery Status:** Battery Status: Normal, On Battery Time: 0 Seconds.
 - Battery Measurement:** Battery Capacity: 100 %, Voltage: 40.8 V, Temperature: 27 °C, Remaining Time: 203 Minute(s).
- Replacement Date:** Last Battery Replacement Date: 10/30/2011 (MM/DD/YYYY), Next Battery Replacement Date: 10/29/2016 (MM/DD/YYYY).

The footer contains the copyright notice: 'Copyright © 2012 Para Systems, Inc. All Rights Reserved.'


5.2.3 In/Out Parameters

Select In/Out Parameters from the UPS Information on the main menu to get a list of the UPS input, and output parameters.



5.2.4 Identification

Select Identification from the UPS Information menu to get a list of the UPS information.



5.2.5 Status Indication

This page lists the UPS events and indicates which event has occurred by turning the button on or off.

The screenshot shows the 'Status Indication' page in the SNMP-NV6 Web interface. The page title is 'Monitor » Information » Status Indication'. The left sidebar contains a navigation menu with 'Status Indication' selected. The main content area displays a list of 20 status indicators, each with a toggle button (a circle with a dot). The 'Buzzer Enabled' indicator is currently turned on (green dot), while all other indicators are turned off (grey dot).

Status Indicator	Toggle State
Economy Mode	Off
Buzzer Enabled	On
UPS Disconnect	Off
Buzzer Alarm	On
Input Out Of Range	Off
Battery Low	Off
Battery Depleted	Off
Battery Need Replace	Off
Battery Ground Fault	Off
Test In Progress	Off
Test Fail	Off
Output Off	Off
On Bypass	Off
UPS System Off	Off
UPS Shutdown	Off
Output Breaker	Off
Output Over Voltage	Off
Output Under Voltage	Off
Overload	Off
Over Temperature	Off
Other Warning	Off
Fan Abnormal	Off
Fuse Abnormal	Off
Inverter Abnormal	Off
Charger Abnormal	Off
Bypass Out Of Range	Off
Emergency Power Off	Off
Phase Asynchronous	Off
Rectifier Abnormal	Off

Copyright © 2012 Para Systems, Inc. All Rights Reserved.

5.2.6 ShutdownAgent

The SNMP-NV6 card will interface with the ShutdownAgent software. See the ShutdownAgent software user's manual to configure the SNMP-NV6 card to communicate with the ShutdownAgent software.

The screenshot shows the 'ShutdownAgent' page in the SNMP-NV6 Web interface. The page title is 'Monitor » Information » ShutdownAgent'. The left sidebar contains a navigation menu with 'ShutdownAgent' selected. The main content area displays a table with columns for IP Address, OS, Countdown (sec), Reason, and Last Touch (sec). One entry is shown with a green dot, indicating it is active.

	IP Address	OS	Countdown (sec)	Reason	Last Touch (sec)
1	192.168.168.157 RobertC7	Microsoft Windows 7 Professional Service Pack 1 (build 7601), 32-bit		None	2

Copyright © 2012 Para Systems, Inc. All Rights Reserved.

5.3 Monitor History

5.3.1 Event Log

This table lists all the events that have occurred. The existing values are overwritten when the maximum number of entries (rows) has been reached. You can also download all of the event logs to your computer.

SNMP-NV6 Web

System Time : Fri 10/12/2012 PM 02:32:11

Monitor » History » Event Log » Page1

Event Log

From 10/12/2012 (MM/DD/YYYY) to 10/12/2012 (MM/DD/YYYY) Apply

Date	Time	Level	Event Log
10/12/2012	14:30:52	Warning	Power restore
10/12/2012	14:30:50	Warning	No longer discharging from battery
10/12/2012	14:30:50	Warning	No longer on battery mode
10/12/2012	14:30:38	Warning	On battery mode
10/12/2012	14:30:38	Warning	Power fail
10/12/2012	14:30:32	Warning	Battery is discharging
10/12/2012	14:07:45	System	admin login to the WEB from 192.168.168.157

Copyright © 2012 Para Systems, Inc. All Rights Reserved.

5.3.2 Data Log

This table lists all of the saved UPS data. The existing values are overwritten when the maximum number of entries has been reached. You can also download the data log to your computer.

SNMP-NV6 Web

System Time : Fri 10/12/2012 PM 02:27:36

Monitor » History » Data Log » 10/12/2012 - 10/12/2012

Data Log


From 10/12/2012 (MM/DD/YYYY) to 10/12/2012 (MM/DD/YYYY) Apply Download

Date	Time	In Volt		In Amp	In Pwr	Out Volt	Out Amp	Out Pwr	Out Load	By Freq	By Volt	By Amp	B
		Lo	Hi										
10/12/2012	14:27:27	59.9Hz	122.4V	123.0V	59.9Hz	121.6V	0.0A	0W	0%				
10/12/2012	14:26:27	59.9Hz	122.6V	123.2V	59.9Hz	121.7V	0.0A	0W	0%				
10/12/2012	14:25:27	59.9Hz	122.6V	123.3V	59.9Hz	122.4V	0.0A	0W	0%				
10/12/2012	14:24:27	59.9Hz	122.6V	123.3V	60.0Hz	122.3V	0.0A	0W	0%				
10/12/2012	14:23:27	59.9Hz	122.6V	123.3V	59.9Hz	122.4V	0.0A	0W	0%				
10/12/2012	14:22:27	59.9Hz	122.6V	123.3V	59.9Hz	122.4V	0.0A	0W	0%				
10/12/2012	14:21:27	59.9Hz	122.6V	123.3V	59.9Hz	122.2V	0.0A	0W	0%				
10/12/2012	14:20:27	59.9Hz	122.6V	123.4V	60.0Hz	122.0V	0.0A	0W	0%				
10/12/2012	14:19:27	60.0Hz	122.9V	123.4V	60.0Hz	122.2V	0.0A	0W	0%				
10/12/2012	14:18:27	60.0Hz	122.2V	123.4V	59.9Hz	122.4V	0.0A	0W	0%				
10/12/2012	14:17:27	59.9Hz	122.5V	123.0V	60.0Hz	121.9V	0.0A	0W	0%				
10/12/2012	14:16:27	60.0Hz	122.4V	122.9V	60.0Hz	121.9V	0.0A	0W	0%				
10/12/2012	14:15:27	60.0Hz	122.5V	123.0V	60.0Hz	122.0V	0.0A	0W	0%				
10/12/2012	14:14:27	60.0Hz	122.4V	122.8V	60.0Hz	121.6V	0.0A	0W	0%				
10/12/2012	14:13:27	60.0Hz	122.2V	122.8V	60.0Hz	121.7V	0.0A	0W	0%				
10/12/2012	14:12:27	60.0Hz	122.2V	122.8V	60.0Hz	121.6V	0.0A	0W	0%				
10/12/2012	14:11:27	60.0Hz	122.3V	122.8V	60.0Hz	121.8V	0.0A	0W	0%				
10/12/2012	14:10:27	60.0Hz	122.2V	122.8V	60.0Hz	121.8V	0.0A	0W	0%				
10/12/2012	14:09:27	60.0Hz	122.5V	123.2V	60.0Hz	121.6V	0.0A	0W	0%				
10/12/2012	14:08:27	60.0Hz	122.7V	123.3V	60.0Hz	122.2V	0.0A	0W	0%				
10/12/2012	14:07:27	60.0Hz	122.7V	123.4V	60.0Hz	122.5V	0.0A	0W	0%				
10/12/2012	14:06:27	59.9Hz	122.9V	123.3V	60.0Hz	121.9V	0.0A	0W	0%				

Copyright © 2012 Para Systems, Inc. All Rights Reserved.

5.3.3 Configure


This page allows you to clear the event log, the data log and assign the time interval to record the data.



5.4 Monitor About

5.4.1 Information

This menu provides important information about the OpenSSL toolkit that the SNMP-NV6 card utilizes.




5.5 Device (UPS) Management

Because different UPSs provide different functions, the UPS you have may not support the same configuration or control items.

5.5.1 Configure

The configure page is designed to set the configurable values of the UPS and/or SNMP card. These values will be stored in the UPS and/or SNMP card.

Note: Different UPS models support different configuration options.



5.5.1.1 Auto Restart

The card sends the command to the UPS to configure the auto restart function.

5.5.1.2 UPS Buzzer

The card sends the command to the UPS to configure the buzzer function.

5.5.1.3 Low Battery

The set value is compared to the received value from the UPS. If the received battery level is lower than the assigned value then the card sends the Low Battery Warning.

5.5.1.4 UPS Shutdown Action

The set value is compared to the received value from the UPS. If the Power Fail or Low Battery event occurs then the card sends the assigned shutdown delay time to the UPS.

5.5.1.5 Smart Shutdown

Initiates a signal for the server to shutdown. After the user-defined Estimated OS Shutdown Delay, the output power is switched off. SNMP-NV6 Client or SNMP ShutdownAgent must be used on the server for it to be properly shutdown. The Estimated OS Shutdown Delay includes the assigned countdown delay in the shutdown software plus the duration of OS shutdown process. When the Shutdown Agent receives the Smart Shutdown signal, the low battery settings will be used to process the shutdown procedure.

5.5.1.6 Battery Replacement Date

After the battery replacement dates are assigned, the card then sends the command to store these dates in the UPS.

5.5.1.7 External Battery Pack

If you are using an External Battery Pack with this UPS, the UPS must be configured so that; the UPS will report the correct estimated runtime.

5.5.1.8 Outlet Banks


Configure the Outlet Banks to turn off once a power event occurs. Turning off non-mission critical equipment once a power event occurs can extend the battery backup time for the mission critical equipment.

5.5.1.9 Economy Mode

Configure the UPS to operate in the Economy mode. See the UPS user's manual for the Economy mode operation.

5.5.2 Control

This menu allows you to send the control commands to the UPS.



5.5.2.1 Battery Test

The card sends the command to the UPS to perform a battery test.

5.5.2.2 Shutdown & Restart UPS Only

The card sends the command to the UPS to perform the Shutdown and/or Restart function.

SNMP-NV6

If you only want to shutdown the UPS mark the UPS Shutdown Delay check box and fill in the delay time.

If you only want to restart the UPS mark the UPS Restart Delay check box and fill in the delay time.

If you want to perform both the shutdown and the restart mark both of the check boxes and fill in both of the delay times.

5.5.2.3 Smart Shutdown

The Smart Shutdown feature is used to shutdown all of the connected computers and the UPS safely.

First you should estimate the longest OS shutdown time of your operating systems, which have the shutdown software installed and are connected to this card. The card will delay the assigned OS shutdown time until all of the operating systems are shutdown by the shutdown software then sends the UPS the shutdown command.

5.5.2.4 Outlet Control

Press the Switch Bank button to control the UPS output relay to turn on or off the outlet banks.

5.5.2.5 Power Fail/Restore Simulation

Pressing one of the buttons causes the card to simulate the UPS power fail or power restore event. Based on this function, we can test all of the connected software to verify whether they work properly or not. The UPS will remain in its original state and will not go to the battery mode.

5.5.3 Weekly Schedule

This menu allows you to modify the parameters of the shutdown/restart/test events associated with the days of the week.


The screenshot shows the 'SNMP-NV6 Web' interface. The top navigation bar includes 'Monitor', 'Device', and 'System' tabs. The 'Management' section is active, with a sidebar menu containing 'Configure', 'Control', 'Weekly Schedule', 'Specific Schedule', and 'Event Level'. The main content area is titled 'Device » Management » Weekly Schedule' and contains a 'Weekly Schedule' table. The table has columns for 'Action', 'SUN', 'MON', 'TUE', 'WED', 'THR', 'FRI', 'SAT', and 'Time'. The following table represents the data shown in the screenshot:

	Action	SUN	MON	TUE	WED	THR	FRI	SAT	Time
1	10-Seconds Test	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	07:00
2	Shutdown	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	19:00
3	Restart	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	06:00
4	No Action	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	00:00
5	No Action	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	00:00
6	No Action	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	00:00

At the bottom of the table is a 'Submit' button. The footer of the page reads 'Copyright © 2012 Para Systems, Inc. All Rights Reserved.' The system time is displayed as 'Fri 10/12/2012 PM 02:19:31'.


5.5.4 Specific Schedule

This menu allows you to modify the parameters of the shutdown/restart/test events associated with certain days of the year.



5.5.5 Event Level


Each individual event can be configured for Information, Warning or Alarm. You can change the event for e-mail or SNMP trap by modifying the event level.



5.6 System Administration


5.6.1 User Manager

The SNMP-NV6 card supports RADIUS. You can assign your RADIUS server to the card for the login authentication through HTTP, Telnet, SSH, FTP, SFTP and EzSetting. If the RADIUS option is disabled then you still can manage the login authentication locally by assigning 3 different level of users account and password.



5.6.2 TCP/IP

This menu allows the administrator to set the local network configuration parameters in SNMP-NV6 card.



5.6.2.1 TCP/IP Settings for IPv4

DHCP Client: Enable/Disable DHCP to get the IP address from DHCP server.

IP Address: The IP address of the card (e.g. 192.168.1.100).

Subnet Mask: The Subnet Mask for your network (e.g. 255.255.255.0).

Gateway IP: The IP address of the network gateway (e.g. 192.168.1.254).

DNS IP: The IP address of the domain name server (e.g. 192.168.1.1).

Search Domain: The system domain name, if the host name you provided cannot be searched then the system will append the search domain to your host name.

5.6.2.2 TCP/IP Settings for IPv6

DHCP Client: Enable/Disable DHCP to get the IP address from DHCP server.

IP Address: The IPv6 address of the card.

Prefix Length: The prefix length for the IPv6 address.

Gateway V6IP: The IP address of the IPv6 network gateway.

DNS V6IP: The IP address of the IPv6 domain name server.

5.6.2.3 System

Host Name: The Host Name of the SNMP-NV6 card.

System Contact: The system contactor information of the network administration.

System Location: The system location of the SNMP-NV6 card.

5.6.2.4 Link

This allows the administrator to set the data transmission for the SNMP-NV6 card to properly work with your network.

5.6.3 Web

This menu allows the administrator to enable or disable the HTTP/HTTPS communication protocols available in the SNMP-NV6 card.

The screenshot displays the 'SNMP-NV6 Web' administration interface. The top navigation bar includes 'Home' and 'Logout' links, and the system time is shown as 'Fri 10/12/2012 PM 02:37:14'. The main content area is titled 'System » Administration » Web' and contains two configuration panels:

- Web Configuration:**
 - HTTP: Enable Disable
 - HTTPS: Enable Disable
 - HTTP Port:
 - HTTPS Port:
 - Web Refresh Period: Seconds
- SSL Certificate Configuration:**
 - Certificate File (PEM format):
 - Update the certificate file, which is generated by openssl for the new SSL connection.
 -

At the bottom of the page, the copyright notice reads: 'Copyright © 2012 Para Systems, Inc. All Rights Reserved.'

5.6.3.1 Web

HTTP: Enabling or disabling the HTTP connection with the SNMP-NV6 card.

HTTPS: Enabling or disabling the HTTPS connection with the SNMP-NV6 card.

HTTP Port: The user may configure HTTP protocol to use a port number other than standard HTTP port (80).

HTTPS Port: The user may configure HTTPS protocol to use a port number other than standard HTTPS port (443).


Web Refresh Period: The period of time to update the web pages.

5.6.3.2 SSL Certificate

Certificate File: This option is used to replace your own SSL certificate file. The SNMP-NV6 card supports PEM format, which is generated by the OpenSSL.

5.6.4 Console

This menu allows the administrator to enable or disable the Telnet/SSH communication protocols available in the SNMP-NV6 card.



5.6.4.1 Console

Telnet: Enabling or disabling the Telnet connection with the SNMP-NV6 card.

SSH/SFTP: Enabling or disabling the SSH/SFTP connection with the SNMP-NV6 card.

Telnet Port: The user may configure Telnet protocol to use a port number other than standard Telnet port (23).

SSH Port: The user may configure SSH protocol to use a port number other than standard SSH port (22).

5.6.4.2 Host Key

DSA/RSA Key: These options are used to replace your own SSH keys. The SNMP-NV6 card supports the key files, which are generated by the OpenSSH.

5.6.4.3 Authentication Public Key

Public Key: Provide the public key to authenticate the SSL connection. The public key can be generated by openssh or putty.

5.6.5 FTP

This menu allows the administrator to enable or disable the FTP communication protocols available in the SNMP-NV6 card.



5.6.5.1 FTP

FTP: Enabling or disabling the FTP connection with the SNMP-NV6 card.

FTP Port: The user may configure FTP protocol to use a port number other than standard FTP port (21).

5.6.6 Time Server

This menu allows you to set the SNMP-NV6 card's internal date and time. There are 2 ways to set the date and time. Synchronize with SNTP server or set the date and time manually.

Note: If the SNTP is enabled, but cannot get any reply from the assigned time server then the event log and data log will not work.



5.6.6.1 Simple Network Time Server

Time Zone: Select the time zone where the SNMP-NV6 card is installed.

Primary/Secondary Time Server: The SNMP-NV6 card searches both of the Time Servers and follows the first reply server's time. The card synchronizes with the Time Server every hour.

Enable Daylight Saving: This option is used to setup a daylight saving time. During the period of daylight saving time, the SNMP-NV6 card will add 1 hour automatically.

5.6.6.2 Manual

If it is not possible to connect to a Time Server then the only way to adjust the system time is manually configure the date and time.

Note: The system date and time will be reset to the assigned date/time if the SNMP-NV6 card is restarted.

5.6.7 Syslog

This menu allows the administrator to set the SNMP-NV6 card's syslog. The syslog feature is used to save the event log to a remote syslog server. This feature does not affect the local event log.



5.6.8 Batch Configuration

If you are the administrator and you have finished configuring one of the SNMP-NV6 cards, you can copy the same configuration to the other SNMP-NV6 cards by distributing the configuration files.

Note: You should only delete the lines which you don't want to distribute and if the IP address is static then you must delete the line of IP address = xxx.xxx.xxx in the [System] section. The batch configuration can be done through FTP.

5.6.9 Upgrade

The easiest way to upgrade the SNMP-NV6 card's firmware is through the web interface. The administrator just needs to assign the firmware file from your local disk then press the Upload button to transmit the firmware file to the SNMP card for upgrading.

Note: The SNMP-NV6 card can also be upgraded using the EzSetting program.

5.7 System Notification

5.7.1 SNMP Access


The SNMP-NV6 card supports the SNMP protocol. You can use an NMS to manage a UPS through a network. You must enter the IP address of the workstation in the **SNMP Access Table** to prevent any unauthorized users from configuring the SNMP-NV6 card via SNMP protocol. The maximum number of IPs is 256.



If you use a workstation with SNMP Manager installed, or if you set more restrictive SNMP access, you can use the **SNMP Access** to add the IP address of the PC, which you use to modify the access permission. If the IP address is set as 0.0.0.0, it means the IP address will be ignored. The SNMP-NV6 card will check the community string first to identify whether the incoming packet is Read Only or not.

5.7.2 SNMPv3 USM (User Based Management)

SNMPv3 is an encryption version of SNMP protocol. Before you can access the SNMP OID from the SNMP-NV6 card using SNMPv3 protocol you have to configure the SNMPv3 USM table.



There can be 8 SNMPv3 users for the SNMP-NV6 card. After configuring the account parameters you can access the card using SNMPv3 protocol. This user table is related to the SNMPv3 Trap.

To test the SNMPv3, find a Linux operating system and open the terminal shell then key in the following command to get the reply:

```
snmpwalk -v 3 -u <user> -l authPriv -A <password> -X <password> -n <context name> -t 3 <ip> 1.3.6.1.2.1.1.1.0
```

Where:

- v: 1 for SNMPv1, 2 for SNMPv2c, 3 for SNMPv3.
- l: Follow the security level, there are noAuthNoPriv, authNoPriv and authPriv.
- u: The user name, which is assigned in the SNMPv3 USM table.
- A: Follow an Auth Password, which is assigned in the SNMPv3 USM table.
- X: Follow a Priv Password, which is assigned in the SNMPv3 USM table.
- n: The Context Name, which is assigned in the SNMPv3 USM table.
- t: Timeout in second.

<ip>:IP address of the SNMP-NV6 card.

<oid>:The available SNMP OID, please refer to the MIB file. For example: 1.3.6.1.2.1.1.1.0

5.7.3 SNMP Trap

If you use a PC and perform the SNMP Manager **Trap** function to manage an UPS through the SNMP-NV6 card, you must add the IP address of the PC to the SNMP Trap list. The maximum number of SNMP trap targets is 256.

	Target IP	Community	Port	MIB	Type	Event Level	SNMPv3 User
1	192.168.168.175	public	162	UPSv4	v1	Information	

The **Event Level** field is used to decide what kind of power event notification should be sent to the target address. There are 3 levels of power events: **Information, Warning and Alarm**. If you select **Information**, the notification of all power events will be sent to the target address; if you select **Warning**, the notification of Warning event as well as Alarm event will be sent to the target address; if you choose **Alarm**, only the notification of Alarm event will be sent to the target address.

The SNMP-NV6 card provides SNMPv1, v2c and v3 traps to satisfy most of customer's environment. If you select the SNMPv3 trap, then one of the user names must be entered into the SNMPv3 USM table.

5.7.4 Mail Server

The administrator can set up the SMTP Mail Server and the e-mail receiver so the designated recipient can receive the e-mail notification from the SNMP-NV6 card whenever a power event occurs. Gmail accounts are supported. The maximum number of e-mail users is 256.

The screenshot shows the 'SNMP-NV6 Web' interface. The top navigation bar includes 'Home' and 'Logout' links, and the system time is 'Fri 10/12/2012 PM 02:42:51'. The main menu has 'Administration' and 'Notification' tabs. The left sidebar lists 'SNMP Access', 'SNMPv3 USM', 'SNMP Trap', 'Mail Server' (selected), and 'Wake On LAN'. The main content area is titled 'System » Notification » Mail Server' and contains a 'Mail Server Configuration' form with the following fields:

- SMTP Server Name or IP: (51 bytes max.)
- SMTP Server Port: 25
- Account: (32 bytes max.)
- Password: (16 bytes max.)

A 'Submit' button is located below the Password field. A note states: 'The Account and Password are not required to send emails.' Below the configuration form is a 'Mail List' section with a 'Receiver' input field, an 'Event Level' dropdown menu (set to 'Information'), and 'Add', 'Update', and 'Delete' buttons. A table below shows one entry:

Receiver	Event Level
1	Information

Copyright © 2012 Para Systems, Inc. All Rights Reserved.

SMTP Server Name or IP: This is the hostname of a SMTP Mail Server used to send the email message from the SNMP-NV6 card. When entering a hostname, you are also required to enter the **DNS IP** in the **TCP/IP** page. Gmail accounts are supported.

SMTP Server Port: Default SMTP server port is 25. This can be changed as required.

Account: The Mail Server's login account (if required).

Password: The Mail Server's login password (if required).

Receiver: Enter the email address that you want the SNMP-NV6 card to send an e-mail to.

Event Level: Select the event level that you want to go to the corresponding e-mail recipient. If you select **Information**, the notification of all power events will be sent to the target address; if you select **Warning**, the notification of the Warning event as well as the Alarm event will be sent to the target address; if you choose **Alarm**, only the notification of the Alarm event will be sent to the target address. You can change the event level from UPS Management – Event Level menu.

5.7.5 Wake On LAN

The Wake On LAN function can start up the client PC from the network by the MAC address. From this page, you can set 256 MAC addresses of the clients to be restarted after the power is restored or when the SNMP-NV6 card starts up.



The screenshot shows the 'WOL Host List' configuration page in the SNMP-NV6 Web interface. The page has a navigation menu on the left with 'Wake On LAN' selected. The main content area contains a form for adding a new host and a table of existing hosts.

WOL Host List Form:

- Title: None
- MAC (xx-xx-xx-xx-xx-xx): 00-00-00-00-00-00
- Delay: 0 minute(s)
- Wake Up Condition: Power Restore System Startup
- Buttons: Add

WOL Host List Table:

	Title	MAC	Delay	Restore	Startup
1	None	00-00-00-00-00-00	0	No	No

Copyright © 2012 Para Systems, Inc. All Rights Reserved.

5.8 Environment

5.8.1 Information

The ENV Probe is an option for the SNMP-NV6 card that supports temperature and humidity and has 4 contact closure inputs for monitoring environmental status such as smoke, fire, water, and security alarms. See the ENV PROBE User's Manual for installation.

Features:

- Environmental temperature and humidity monitoring.
- Attaches up to 4 contact closure inputs for monitoring other environmental devices.
- Allows remote monitoring through network.



The screenshot shows the 'Environment Information' page in the SNMP-NV6 Web interface. The page displays sensor information and input contacts.

Environment Information Table:


Sensor Information	Input Contacts	Contact Setting
Temperature: 26.0 °C 78.8 °F	Smoke(R1): Normal	Smoke(R1): Normal Open
Humidity: 22 %	Fire(R2): Normal	Fire(R2): Normal Open
	Leak(R3): Normal	Leak(R3): Normal Open
	Door(R4): Normal	Door(R4): Normal Open

Copyright © 2012 Para Systems, Inc. All Rights Reserved.

5.8.2 Configuration

This page allows you to change the values in the Temperature Warning and Alarm Thresholds and Humidity Warning and Alarm Thresholds, and then click on the Submit button to update the changes. If the temperature or humidity exceeds the alarm threshold, the event will be displayed in red on the Event log page. The ENV Probe can be configured to send an SNMP trap to the assigned target hosts.

Select normal open or normal close for each of the 4 options, and then click on the Submit button to update the changes. If an alarm for one of the 4 input contact closures occurs, the alarm will be displayed in red on the Event log page. The 4 input contact closures can be configured to send an SNMP trap to the assigned target hosts.




6. Upgrade


The **EzSetting** program can be used to perform the firmware upgrade. The **EzSetting** program is compatible with the Windows operating system.

Note: The firmware can also be upgraded by using the upgrade function in the web interface.

1. Make sure the SNMP-NV6 card is in the Subnet that has been specified. If it is not in the specified subnet configure the subnet and subnet mask to match the SNMP-NV6 card that you want to upgrade.
2. Press the Discover button to search for all of the SNMP cards in the specified subnet.




3. Select one device in the Device List then press the Modify button to enter the Account and Password.




SNMP-NV6


4. On the main screen press the Upgrade button. When the upgrade dialog box appears press the Browse button to locate the new firmware file. Verify the firmware version is the new file, which is listed in the File Information field then press the Upgrade Now button. The SNMP-NV6 card will response to the upgrade request in approximately 20-seconds



5. After the upgrade procedure is finished, the following dialog box will appear. Please wait approximately 1-minute for SNMP-NV6 card to reboot.



6. The EzSetting program supports Batch Upgrading. Select the checkboxes of the devices, which are listed in the Device List, then press the Batch Upgrade button. Select the firmware file, enter the Account name and Password, and then press the Upgrade Now button to upgrade all of the selected devices sequentially.



7. Specifications

7.1 Technical Specifications

Network Connection	RJ-45 connector
Operating Temperature	0 ~ 40° C
Operating Humidity	10 ~ 80 %
Power Input	9~24V DC
Power Consumption	2 Watt Maximum
Size	130 mm x 60 mm (L x W)
Weight	75g

7.2 DIP Switch Settings

No.	Dip1	Dip2	Description
1	OFF	OFF	Normal operation
2	OFF	ON	N/A
3	ON	OFF	Sensor Mode (with ENV Probe)
4	ON	ON	Console Mode

7.3 LED Indicators

No.	Yellow LED	Green LED	Description
1	---	OFF	Hardware or network error
2	Flashing (1sec)	---	UPS Disconnected
Without ENV Probe			
3	Flashing (50 ms)	ON	Normal operation
With ENV Probe			
4	Flashing (50 ms)	Flashing (50 ms)	Normal operation
5	Flashing (50 ms)	ON	ENV Probe Disconnected

8. Troubleshooting

1. How do I setup a SNTP (Simple Network Time Protocol) server?

Answer: In the Windows XP operating system, click **Start** → select **Control Panel** → choose **Add/Remove Programs** → click the **Add/Remove Windows Components** button → click **Networking Services** → select the **Simple TCP/IP Services** check box → and then click 'OK' to finish the installation of **Simple TCP/IP Services**. After that, enter in the host's IP address on the **Time Server** page.

2. How do I verify the network connection between my workstation and the SNMP-NV6 card?

Answer: Check the network connection by typing the following command **ping HostName or IP** address at your workstation.

3. In the Web Browser, I can see the Login page but cannot login.

Answer: Please check the IP address of the SNMP-NV6 card and the PC you trying to login from. If both of the IP addresses are not in the same LAN, run the **EzSetting** program to configure the **User Limitation** to **Allow Any**.

4. How do I refresh the NetBIOS table in Windows operating system?

Answer: Sometimes the IP address of the SNMP-NV6 card will be changed, but the host name will remain the same. Although Windows will update its NetBIOS table periodically, you can force it to purge its cache immediately by typing the command **nbtstat -R** in the shell. After that, you can connect to the SNMP-NV6 card by its host name.

5. How can I get the IP address and MAC address of my computer?

Answer: For Windows system: type **ipconfig /all** at the DOS prompt. For UNIX system: enter **ifconfig** in the shell.

6. I am unable to ping or connect to the SNMP-NV6 card?

Answer: Check the following items:

- 1) Check all the network connections.
- 2) Ensure that your PC and the SNMP-NV6 card are in the same network segment. If you don't have a router, they must be in the same network segment.
- 3) You can connect to the SNMP-NV6 card only, if your PC and the SNMP-NV6 cards are using the IP addresses from the same IP address block. Normally, private LANs use the IP addresses from one of the following blocks.

10.0.0.0 ~ 10.255.255.255

172.16.0.0 ~ 172.31.255.255

192.168.0.0 ~ 192.168.255.255

The SNMP-NV6 card's default IP address (192.168.1.100) is from the last block. If your LAN is using a different address block, you will not be able to connect to the SNMP-NV6 card via the LAN.

Under such situation, you can choose to:

- Use the **Terminal Mode** to reset the SNMP-NV6 card's IP address.
- Change your PC's IP address to allow connection via the LAN.

7. I am unable to perform the SNMP Get operation?

Answer: Check the SNMP settings stored in the SNMP-NV6 card. The IP address of the PC you are using must be entered in one of the SNMP Access Control NMS IP fields, with Read or Read/Write permission. The community string on the PC and the SNMP-NV6 card must match.

8. I am unable to perform the SNMP Set operation?

Answer: Check the SNMP settings stored in the SNMP-NV6 card. The IP address of the PC you are using must be entered in one of the SNMP Access Control NMS IP fields, with Read/Write permission. The community string on the PC and the SNMP-NV6 card must match.

9. I do not receive traps at my management station?

Answer: Check the SNMP Trap settings in the SNMP-NV6 card. The IP address of the PC you are using must be entered in one of the Target IP fields.

10. I forgot my administrator's account and password?

Answer: Connect the RJ45 to DB9 serial cable to the console port on the SNMP-NV6 card and set both of the dipswitches to the **ON** position (configuration mode). Enter **rstadmin** within 30 seconds while the **Account** and **Password** are prompted. After that, the administrator's account and password are now reset to the default values.

11. Where can I get information about IPv6?

Answer:

- 1) For every device that supports IPv6, it will have a LLA (Link Local Address) generated according to its own MAC address and the EUI-64 standard algorithm. For example, if the MAC address is **00:11:22:33:44:55**, the according LLA will be fe80::211:22ff:fe33:4455. The SNMP-NV6 card does support IPv6 and can directly connected via LLA without any additional configuration. You should note that, according to RFC-4862, the IPv6 interface will automatically shutdown if the same LLA already existed on the LAN.
- 2) If both of the IPv4 and IPv6 DNS configurations co-exist, the IPv4 DNS configuration will have the top priority.
- 3) If your operating system is Windows XP, please enable IPv6 first (select **RUN** from **START** and enter **ipv6 install**).
- 4) To know more about IPv6 compatibility information, refer to RFC documents (1981, 2460, 4861, 4862, and 4443) on **IETF** website (<http://tools.ietf.org/html>), or refer to **IPv6 Ready Logo** website (<http://www.ipv6ready.org>).

12 How do I generate a private SSL certificate file (PEM format) for HTTPS?

Answer:

- 1) Download the openssl from <http://www.openssl.org> and install it on the Linux machine.
- 2) Open the command shell and enter the following command to create your own certificate file:

Openssl req -x509 -nodes -days 3650 -newkey rsa:1024 -keyout cert.pem -out cert.pem

- 3) Once it is complete the cert.pem will be created in the current working directory.
- 4) Upload the cert.pem file to the SNMP-NV6 card through the web page.

13 How do I generate the SSH DSA and RSA keys for SSH?

Answer:

For Linux Version:

- 1) Download the openssh from <http://www.openssh.org> and install it on the Linux machine.
- 2) Open the command shell and enter the following command to create your own keys: Ignore the passphrase when ask.
DSA Key: ssh-keygen -t dsa
RSA Key: ssh-keygen -t rsa
- 3) Upload the DSA and RSA key files to the SNMP-NV6 card through the web page.

For Windows Version:

- 1) Download the Putty from <http://www.putty.org> and install it.
- 2) Run the **puttygen.exe** in the putty installed directory.
- 3) Select **SSH-2 RSA** from the Parameters area and select the **Generate key pair** from the **Key** menu to generate the RSA key.
- 4) Select **Export OpenSSH Key** from the **Conversions** menu and assign a file name for the RSA key. Ignore the passphrase when ask.
- 5) Select **SSH-2 DSA** from the Parameters area and select the **Generate key pair** from the **Key** menu to generate the DSA key.
- 6) Select **Export OpenSSH Key** from the **Conversions** menu and assign a file name for the DSA key. Ignore the passphrase when ask.
- 7) Upload the DSA and RSA key files to the SNMP-NV6 card through the web page.

9. Limited Product Warranty

Para Systems Inc. (Para Systems) warrants this equipment, when properly applied and operated within specified conditions, against faulty materials or workmanship for a period of three years from the date of original purchase by the end user. For equipment sites within the United States and Canada, this warranty covers repair or replacement of defective equipment at the discretion of Para Systems. Repair will be from the nearest authorized service center. Replacement parts and warranty labor will be borne by Para Systems. For equipment located outside of the United States and Canada, Para Systems only covers faulty parts. Para Systems products repaired or replaced pursuant to this warranty shall be warranted for the remaining portion of the warranty that applies to the original product. This warranty applies only to the original purchaser who must have properly registered the product within 10 days of purchase.

The warranty shall be void if (a) the equipment is damaged by the customer, is improperly used, is subjected to an adverse operating environment, or is operated outside the limits of its electrical specifications; (b) the equipment is repaired or modified by anyone other than Para Systems or Para Systems-approved personnel; or (c) has been used in a manner contrary to the product's operating manual or other written instructions.

Any technical advice furnished before or after delivery in regard to use or application of Para Systems' equipment is furnished without charge and on the basis that it represents Para Systems' best judgment under the circumstances, but it is used at the recipient's sole risk.

EXCEPT AS PROVIDED HEREIN, PARA SYSTEMS MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation of implied warranties; therefore, the aforesaid limitation(s) may not apply to the purchaser.

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL PARA SYSTEMS BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, Para Systems is not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, cost of substitutes, claims by third parties, or otherwise. The sole and exclusive remedy for breach of any warranty, expressed or implied, concerning Para Systems' products and the only obligation of Para Systems hereunder, shall be the repair or replacement of defective equipment, components, or parts; or, at Para Systems' option, refund of the purchase price or substitution with an equivalent replacement product. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.