

A1 Firmware Upgrade

This menu allows the administrator to upgrade the firmware of the RPM1521.

Firmware Upgrade

IP: 192.168.168.235

Production Data

Production Name: RPM1521
IP Address: 192.168.168.235
Subnet Mask: 255.255.255.0
MAC Address: 00:1F:16:BE:0E:5F
Current Firmware Version: 2.0.081028

Firmware File Data

File Type: System
Production Name: RPM1521
Firmware Version: 2.0.081028j

Firmware File: U:\Projects Active\1 1 New RPM\Bellwin\SP2L\1 Fi ...
PassWord: admin

Update Progress

UpDate Progress[0%]..

Firmware Upgrade Procedure:

1. Open the firmware_upgrade.exe program located on the RPM1521 CD.
2. Input the IP Address of the RPM1521.
3. Click on the GetVersion button.
4. Click on the browse (...) button to search for the new firmware file (.bin).
5. Input the password (default is admin).

Firmware Upgrade

IP: 192.168.168.235

Production Data

Production Name: RPM1521
IP Address: 192.168.168.235
Subnet Mask: 255.255.255.0
MAC Address: 00:1F:16:BE:0E:5F
Current Firmware Version: 2.0.081028

Firmware File Data

File Type: System
Production Name: RPM1521
Firmware Version: 2.0.081028j

Firmware File: U:\Projects Active\1 1 New RPM\Bellwin\SP2L\1 Fi ...
PassWord: admin

Firmware Update

Wait for firmware update...(Do not reset or power off device during waiting.)

6. Click on the Upgrade button to start the firmware upgrading process.
7. Once the firmware upgrading process is complete the RPM1521 will reboot.
8. Once the reboot is complete click the OK button.
9. This completes the Firmware Upgrade process.